


Flow Totalizer

Installation and Operation Guide



Content

Part 1 Menu Operation.....	1
1.1 Menu instruction.....	1
1.1.1 Operation Interface.....	1
1.1.2 Display Screen.....	2
1.2 Main Menu.....	2
1.3 Query and Export.....	3
1.3.1 Query Submenu.....	3
1.3.2 Day Record.....	3
1.3.3 Monthly Record.....	3
1.3.4 Year record.....	3
1.3.5 Log record.....	4
1.3.6 Export record.....	4
1.3.7 Export log.....	5
1.5 Input setup.....	6
1.5.2.2 Mass Flow.....	12
1.5.2.3 DP Flow.....	13
1.5.2.4 Orifice DP.....	15
1.5.2.5 V-Cone DP.....	17
1.5.2.6 Annubar DP.....	19

1.5.2.7 Elbow DP	21
1.5.2.8 Linear current.....	23
1.5.2.9 Damping and log interval.....	24
1.5.2.10 Low Flow Cutoff.....	24
1.5.2.11 Flow factor.....	24
1.5.2.12 Temperature signals.....	25
1.5.2.13 Pressure signals.....	26
1.7 Total reset.....	30
1.7.1 Total reset.....	30
1.7.2 Log reset.....	30
1.8.1 Current output calibrate.....	31
1.8.2 Current input calibrate.....	32
1.8.3 Temperature Input.....	32
1.9 Display unit.....	33
1.10 Password.....	34
1.11 Date and time.....	34
1.12 Self-test.....	34
Part 2 Wirings.....	35
2.1 Wiring Terminals.....	35
2.2 Terminals Definition.....	35

Part 1 Menu Operation

1.1 Menu instruction

1.1.1 Operation Interface



ALM1: Alarm indicator of Alarm 1

ALM2: Alarm indicator of Alarm 2

TXD1: Indicator of data sending

RXD2: Indicator of data receiving

MENU key: Enter to next menu, enter main menu in measuring screen, and switch to next parameter in setup menu.

- ↑ : Up key, move the cursor upward, and increase the value in setup menu.
- ↓ : Down key, move the cursor downward, and reduce the value in setup menu.
- << : Left key, move the cursor leftward, and Shift the flashing digit position to left in setup menu.
- >> : Right key, move the cursor rightward, and Shift the flashing digit position to right in setup menu.

Prompt line

OK	ERR	ST	SP	TP	mA	ALM1	ALM2
Working well	Abnormal working	Set the temperature compensation	Set the pressure compensation	Temperature and pressure at the same time set compensate	Current output over range	Alarm 1, up arrow for the upper limit alarm, down arrow for the lower limit alarm.	Alarm 1, up arrow for the upper limit alarm, down arrow for the lower limit alarm.

00103: Instrument communication state information display, before three are expressed mailing address, and the four said the parity bit, 0: no parity; 1: odd parity; 2: parity check; fifth, said the baud rate, the 0:1200; 1:2400; 2:4800; 3:9600.

1.1.2 Display Screen

Flow rate	
1. Prompt information	0 K S T AL1 AL2 00103
2. Flow rate	0.000 m ³ /h
3. Flow totalizer	00000000.000m ³
4. Temperature and pressure	-123.8°C 2758.5kPa
Input signal	
1. F:Frequency; I:Current	F: 0.00 I: 0.000
2. Pressure current	PI: 0.000 mA
3. Temperature current	TI: 0.000 mA
4. Clock	2018-01-01 17:21
Measuring	
1. Temperature	Tem.: 180.0°C
2. Pressure	Pre.: 800.000 kPa
3. Density	Den.: 1000.0kg/m ³
4. Differential pressure	D.P.: 0.000 kPa

In the display interface, press the right key to view the interface on the left.

1.2 Main Menu

In display screen, press MENU key to enter main menu.

- 1.Query and exp.
- 2.Com set
- 3.Input setup
- 4.Output setup

- 5.Total reset
- 6.Calibration
- 7.Display unit
- 8.Password

- 9.Date and time
- 10.Self-test

1.3 Query and Export

1.3.1 Query Submenu

In main menu, press Up or Down key to select Query submenu, and then press MENU key to enter.

In Query submenu, there are records of Daily, Monthly, Year, Log read; Export date and year records and log records.

Press Up or Down key to select the inquiry record and Export records, and then press MENU key to Submenu.

1.3.2 Day Record

Press Up or Down key to select Day Record, and then press MENU key to enter, shown as below.

- 1.Day record
- 2.Month record
- 3.Year record
- 4.log record

Day record:

2017-12-10
20.325

Daily consumption,
Unit with the flow total unit

Year/Month/Day: Press Right or Left key to select year, month or day, and press Up or Down key to select the needed day.

1.3.3 Monthly Record

Press Up or Down key to select Monthly Record, and then press MENU key to enter, shown as below.

- 1.Day record
- 2.Month record
- 3.Year record
- 4.log record

Month record:

2017-12
11.325

Month consumption,
Unit with the flow total unit

Year/Month: Press Right or Left key to select year or month, and press Up or Down key to select the needed month.

1.3.4 Year record

Press Up or Down key to select Year record, and then press MENU key to enter, shown as below.

- 1.Day record
- 2.Month record
- 3.Year record
- 4.log record

Month record:


2017
11.325

Year consumption,
Unit with the flow total unit

Year: Press Up or Down key to select the needed year.


1.3.5 Log record

Press Up or Down key to select log record, and then press MENU key to enter, shown as below.



1.3.6 Export record

Press Up or Down key to select Export record, and then press MENU key to enter, shown as below. There is no option without USB interface.



The export data format is ". Csv", There are three export documents, there are days, months, years. And the data can be opened in the computer EXCEL software. The data is shown in the following diagram. As shown below.

	A	B
1	08/08/201	26.63456
2	25/12/201	16.09522

Data

	A	B
1	01/2018	13.7734
2	08/2017	26.63456


Monthly record

	A	B
1	2017	2.067084
2	2018	13.7734

Year record

1.3.7 Export log

Press Up or Down key to select Export log, and then press MENU key to enter, shown as below. No USB interface, no this option.



The export data format is “. Csv”, And the data can be opened in the computer EXCEL software. The data is shown in the following diagram. As shown below.

	A	B	C	D	E	F
1	DATE	TIME	TOTAL	FLOW	TEMPERATURE	PRESSURE
2	08/08/201	0:00:02	13.773	0	180	800
3	08/08/201	0:00:03	13.773	0	180	800

1.4 Communication setup

In main menu, press the MENU key to enter the menu interface, press Up or Down key to select Communication setup submenu, and then press ENTER key to enter. shown as below.

Com1 parameter Device ID: 001 Baud rate: 9600 Parity: NONE	Device ID:0-999 RS485 communication setup: Meters address range: 0~255. Baud rate can be selected 1200, 2400, 4800 and 9600. Parity check can be selected: none, odd and even. After the communication is set, press the MENU key button to enter the mode selection. Communication mode selection, RTU, ASCII two modes, data arrangement information selection includes 3412,1234. set parameters press Right key to shift cursor, and then press Up/Down key to set the values.
Com1 parameter Modbus: RTU Endian: 3412	

1.5 Input setup

This submenu affects the performance and accuracy of instrument, please be careful when operating. Set the flow signal parameters, temperature parameters, pressure parameters. In main menu, press Up or Down key to select Setup submenu, and then press MENU key to enter.

- 1.Query and exp.
- 2.Com set
- 3.Input setup**
- 4.Output setup

Setup Password

0*****

- 1.Flow signals**
- 2.Tempe signals
- 3.Press signals

Note: The input setup submenu has password protection. When inputting password, press Left key to shift the cursor, and press Up or Down key to increase or decrease the number. The default password is 000000, users can modify the password according to 1.10 Password.

1.5.1 Flow signals

1.5.1.1 Medium Options

In the input setup menu select the flow signal Press the MENU key to enter the submenu, press MENU key to enter "Medium" select.

- 1.Flow signals
- 2.Tempe.signals
- 3.Press.signals

Medium select:
Liquid(volume)

Medium Options

- 1. Liquid (Volume)
- 2. Liquid (Mass)
- 3. Constant Density
- 4. Vapor (Auto): Vapor Automatic Compensation
- 5. Saturated stm. T: Saturated vapor temperature compensation
- 6. Saturated stm. P: Saturated vapor pressure compensation
- 7. Superheated stm.: Superheated vapor pressure and temperature compensation
- 8. Gas (Std. volume)
- 9. Gas (Oper. volume)
- 10. Gas (Mass)

1.5.1.2 Liquid (Volume)

In medium menu, then press Up key to select Liquid (Volume).

Press MENU key to shift cursor on density value, and then press Up/Down key to change this value.

After set Density (20°C), press Left key to shift cursor on Density (20°C), press Up key to change Density (20°C) to Coe.V-expansion (Expansibility factor), press Right key to shift cursor on factor value, and then press Up/Down key to change this value.

Medium select:
Liquid (Volume)

Coe.V-expansion
:
0.000000
Density(20°C):

1.5.1.3 Liquid (Mass)

In medium menu, then press Up key to select Liquid (Mass).

Press MENU key to shift cursor on density value, and then press Up/Down key to change this value.

After set Density (20°C), press Left key to shift cursor on Density (20°C), press Up key to change 20°C density to Coe.V-expansion (Expansibility factor), press Right key to shift cursor on factor value, and then press Up/Down key to change this value.

Medium select:
Liquid(mass)

Coe.V-expansion:
0.000000
Density(20°C):
1000.0000 kg/m³

1.5.1.4 Density Compensation

In medium menu, press Left key to shift cursor on Constant density,

Press MENU key to shift cursor on density value, and then press Up/Down key to change this value.

Medium select:
Constant density

Constant density:
1000.0000kg/m³

1.5.1.5 Vapor (Auto)

In medium menu, Press Up key to select Vapor (Auto), press Right key to shift cursor to option content, Press MENU to enter the temperature and pressure compensation priority selection, and then press Down key to select pressure priority or temperature priority.

Medium:
Vapor (Auto)

Vapor auto opt:
Temp.priority

Pres. priority: Include high temperature condensate water, pressure compensation priority.

Temp. priority: Only measure dry saturated vapor, temperature compensation priority.

Medium select:
Saturated stm. T

Medium select:
Saturated stm. P

Medium select:
Superheated stm.

When measuring vapor, there are another three selections: Saturated vapor temperature compensation, Saturated vapor pressure compensation and Superheated vapor pressure and temperature compensation.

1.5.1.6 Gas (Std. Volume)

In medium menu, press Up key to select Gas (Std. volume). Compensation is the temperature and pressure compensation of common gas, and the unit of flow rate is Nm³/h.

Press MENU key to density Submenu, need to set the standard density and standard temperature. Right key to move the cursor position, and then press Up/Down key to change this value.

Medium:
Gas (Std. volume)

Std. density:
0001.2048 kg/m³
Std. temp:20°C

1.5.1.7 Gas (oper. Volume)

In medium menu, press Up key to select Gas (Std. volume). Compensation is the temperature and pressure compensation of common gas, and the unit of flow rate is m³/h.

Press MENU key to density Submenu, need to set the standard density and standard temperature. Right key to move the cursor position, and then press Up/Down key to change this value.

Medium:
Gas (oper. volume)

Std. density:
0001.2048 kg/m³
Std. temp:20°C

1.5.1.8 Gas (Mass)

In medium menu, press Up key to select Gas (Mass). Compensation is the temperature and pressure compensation of common gas, and the unit of flow rate is t/h.

Press MENU key to density Submenu, need to set the standard density and standard temperature. Right key to move the cursor position, and then press Up/Down key to change this value.

Medium:
Gas (Mass)

Std. density:
0001.2048 kg/m³
Std. temp:20°C

1.5.2 Flowmeter type:

After set the media, press the MENU button to enter the flow sensor input type submenu. Press to up key switch the sensor type during set.

This submenu affects the performance and accuracy of instrument, please be careful when operating.

In main menu, press Up or Down key to select Setup submenu, and then press menu key to enter.

1.Query and exp.	Setup Password	1.Flow signals	Medium select:	Flowmeter type:
2.Com set	0*****	2.Tempe.signals	Saturated stm. T	Veloc. /PD
3.Input setup		3.Press.signals		
4.Output setup				

Before set, please confirm the meter type. The meter types are shown as below.


1. Veloc. /PD: Velocity/Volume	4. Orifice DP: Orifice plate DP	7. Elbow DP
2. Mass Flow	5. V cone DP	8. Linear: Linear current
3. DP scale: DP flow	6. Annubar DP	9.K Coe DP

(DP: Differential Pressure)

After set the meter type, by pressing the MENU key button to switch the sensor type related options.

1.5.2.1 Veloc. /PD

The meter type “Veloc. /PD” includes Volumetric flowmeters and Velocity type flow meters, shown as below.



After set meter type, Press the MENU button to switch to the signal selection submenu. There are two parameters in Veloc. /PD: Pulse (Volume), 4-20mA (Volume).

When choosing different signal type, the related parameters will vary, shown as below.

Pulse		4-20mA	
1. Signal type	3. Coefficient linearity	1. Signal type	3. Flow unit
2. Cut-off frequency	4. Flow coefficient	2. Flow scale	4. Cut-off current

1.5.2.1.1 Pulse

In input setup, press Up or Down key to select flow signals submenu, press MENU key to Flowmeter type Submenu .and then press Up/Down key to select “Veloc. /PD”.

In the signal type menu, press the up key to select the signal type (Pulse), After set the flow type, press the MENU key to switch the options once to set the flow coefficient, cut off the frequency, frequency segmentation correction.

Flowmeter type:
Veloc. /PD

Sign type:
Pulse

Flow K:
00200.0000 1/L

Cut-off fieg.:
0000 Hz
Coef. line.: OFF

If you do not choose coefficient correction, just set FLOW K. When set, press the right button to set the cursor position, up and down keys to change the value.

After the Flow k set is completed, press the MENU key to set the Cut-off fieg. value. (Cut-off pulse is set according to different flowmeters on site)

After set Cut-off frequency, press Left key to shift cursor on Cut-off freq., and then press Up key to change Cut-off freq. to Coefficient linearize (Coefficient linearize is used for linearity correction, default setup is “OFF”).

Cut-off fieg.:
0000 Hz
Coef. line.: ON

Flow coe.: Sect 0
Freq: 0000
Coe.:000000.0000

Note: If coefficient linearity is set ON, Press the MENU button to enter the correction factor menu, press the right key to set the cursor position, the up and down keys to change the value.After set, press ENTER key to enter next menu.

Flow coefficient:

When set flow coefficient, it can set by section, the number of section is 0-9.

Freq: Frequency of section, the input range is 0-9999.

Coe: Flow coefficient corresponding to different section. After calibration, input the frequency of section and flow coefficient from section 0 to section 9. Note: If the ten sections are not all in use, for example, there are five sections in use (Section 0 to section 4), set section of frequency 5000 and flow coefficient of section 4 in section 5.

1.5.2.1.2 4-20Ma

In input setup, press Up or Down key to select flow signals submenu, press menu key to Flowmeter type Submenu ,and then press Up/Down key to select “Veloc. /PD”.

In the signal type menu, press the up key to select the signal type (4-20mA), After set the flow type, press the MENU key to switch the options once, set the flow range, cut off the current.

Flowmeter type:
Veloc. /PD

Sign type:
4-20mA

Flow scale:
00001000.000
Unit: m3/h

Cut-off current:
4.0030 mA

When set Flow scale, press the right button to set the cursor position, up and down keys to change the value (The Flow full scale should be the same as that of flowmeters).

After the range set is completed, press the MENU key to set the cut-off current value. (Cut-off current is set according to different flowmeters on site)

1.5.2.2 Mass Flow

In input setup, press Up or Down key to select flow signals submenu, press MENU key to Flowmeter type Submenu, and then press Up/Down key to select “Mass flow”.

1.Flow signals
2.Tempe.signals
3.Press.signals

Medium select:
Saturated stm. T

Flowmeter type:
Mass flow

Flow K:
00200.0000 1/kg

There are two parameters in Mass Flow: Pulse (Mass), 4-20mA (Mass).
The setup method of mass flow is the same as that of Veloc. /PD.

1.5.2.3 DP Flow

In input setup, press Up or Down key to select flow signals submenu, press menu key to Flowmeter type Submenu ,and then press Up/Down key to select “DP Scale”.

1.Query and exp.	Setup Password 0*****	1.Flow signals 2.Tempe.signals 3.Press.signals	Medium select: Saturated stm. T	Flowmeter type: DP scale
Sign type: 4-20mA no sqrt	Note: Orifice plate, V-Cone, Annubar, venture tube and Elbow are all belong to differential pressure flowmeter, and the output signal is scale mass flow.			

After the flowmeter type is set, press the MENU key to switch to the signal type submenu. There are two signal types: 4-20mA No sqrt, 4-20mA sqrt. In this manual, it only introduces 4-20mA No sqrt, the others refer to 4-20mA No sqrt. Press Up key to select different signal types.

- 4-20mA No sqrt: means that the output signal of differential pressure transmitter is no square root signal, this kind signal should be extracted the square root and then can take part in computation.
- 4-20mA Sqrt: means that the output signal of differential pressure transmitter is linear signal, this kind signal does not need to be extracted the square root.

After set signal type, Press MENU to switch to the scale flow range and unit set submenu, Press the right button to move the cursor position, the up and down keys to modify the value. (The range of DP flow is 0-9999999.999) , Press Right key to shift cursor on unit t/h, and then press Up key to select different units (t/h and Kg/h).

DP flow:
00000000.000
Flow unit: t/h

After the scale flow set is completed, press the MENU key to enter the Design density submenu. Press the right button to move the cursor position, the up and down keys to modify the value.

Design density:
0000.0000 kg/m³

After the Design density set is completed, press the MENU key to enter the Flow Coefficient submenu. Press the right button to move the cursor position, the up and down keys to modify the value. (This parameter need not be set)

Flow coe.:
0000.0000

DP scale:
Lower: +0000.000
Upper: +0000.000
Unit: kPa

Note: When shifting the cursor on the +/- symbol, press Up key to switch positive and negative pressure.
The range of DP low limit is 0-999.999.

After the Flow Coefficient set is completed, press the MENU key to enter the DP scale submenu. Press the right button to move the cursor position, the up and down keys to modify the value. Press the right button to move the cursor to DP unit (Differential pressure unit), and then press Up/Down key to select different units (Pa, KPa and MPa).

Cut-off current:
4.0030 mA

After set the differential pressure range, press the menu button to enter the Cut-off current sub-menu. Press the right button to move the cursor position, the up and down keys to modify the value. Cut-off current is set according to different flowmeters on site. Generally, do not need to set this parameter.).

1.5.2.4 Orifice DP

In input setup, press Up or Down key to select flow signals submenu, press menu key to Flowmeter type Submenu ,and then press Up/Down key to select "Orifice DP".

- 1.Query and exp.
- 2.Com set
- 3.Input setup
- 4.Output setup

Setup Password
0*****

- 1.Flow signals
- 2.Tempe.signals
- 3.Press.signals

Medium select:
Saturated stm. T

Flowmeter type:
Orifice DP

There are nine parameters in Orifice DP: Signal type, Pipe diameter, Hole diameter, Expansibility, Flow Coefficient, DP unit, DP low scale, DP high scale and Cut-off current.

After the flowmeter type is set, press the MENU key to switch to the signal type submenu. There are two signal types: 4-20mA No sqrt, 4-20mA sqrt. In this manual, it only introduces 4-20mA No sqrt, the others refer to 4-20mA No sqrt. Press Up key to select different signal types.

Sign type:
4-20mA no sqrt

After set Signal type, press menu key to Pipe Diameter Submenu, press Right key to shift cursor on Cursor position, and then press Up/Down key to change this value.

Pipe diameter:
0000.0000 mm

After set Pipe Diameter, press menu key to Hole Diameter Submenu, press Right key to shift cursor on Cursor position, and then press Up/Down key to change this value.

Hole diameter:
0000.0000 mm

After set Hole diameter, press menu key to Expansibility Submenu, press Right key to shift cursor on Cursor position, and then press Up/Down key to change this value.

Expansibility:
0.00000

After set Expansibility, press menu key to Flow coe. Submenu, press Right key to shift cursor on Cursor position, and then press Up/Down key to change this value.

Flow coe.:
0000.0000

DP scale:
Lower: +0000.000
Upper: +0000.000
Unit: kPa

Note: When shifting the cursor on the +/- symbol, press Up key to switch positive and negative pressure.
The range of DP low limit is 0-999.999.

After the Flow Coefficient set is completed, press the MENU key to enter the DP scale submenu. Press the right button to move the cursor position, the up and down keys to modify the value. Press the right button to move the cursor to DP unit (Differential pressure unit), and then press Up/Down key to select different units (Pa, KPa and MPa).

Cut-off current:
4.0030 mA

After set the differential pressure range, press the menu button to enter the Cut-off current sub-menu. Press the right button to move the cursor position, the up and down keys to modify the value. Cut-off current is set according to different flowmeters on site. Generally, do not need to set this parameter.).

1.5.2.5 V-Cone DP

In input setup, press Up or Down key to select flow signals submenu, press menu key to Flowmeter type Submenu ,and then press Up/Down key to select "V-Cone DP".

- 1.Query and exp.
- 2.Com set
- 3.Input setup
- 4.Output setup

Setup Password
0*****

- 1.Flow signals
- 2.Tempe.signals
- 3.Press.signals

Medium select:
Saturated stm. T

Flowmeter type:
V-Cone DP

There are nine parameters in V-Cone DP: Signal type, Pipe diameter, Cone diameter, Expansibility f, Flow Coefficient, DP unit, DP low scale, DP high scale and Cut-off current.

After the flowmeter type is set, press the MENU key to switch to the signal type submenu.
There are two signal types: 4-20mA No sqrt, 4-20mA sqrt. In this manual, it
only introduces 4-20mA No sqrt, the others refer to 4-20mA No sqrt. Press Up
key to select different signal types.

Sign type:
4-20mA no sqrt

After set Signal type, press menu key to Pipe Diameter Submenu,
press Right key to shift cursor on Cursor position, and then
press Up/Down key to change this value.

Pipe diameter:
0000.0000 mm

After set Pipe Diameter, press menu key to Cone Diameter Submenu,
press Right key to shift cursor on Cursor position, and then press Up/Down
key to change this value.

Cone diameter:
0000.0000 mm

After set Cone Diameter, press menu key to Expansibility Submenu
press Right key to shift cursor on Cursor position, and then press Up/Down
key to change this value.

Expansibility:
0.00000

After set Expansibility, press menu key to Flow coe. Submenu,
press Right key to shift cursor on Cursor position, and then press Up/Down
key to change this value.

Flow coe.:
0000.0000

DP scale:
Lower: +0000.000
Upper: +0000.000
Unit: kPa

Note: When shifting the cursor on the +/-
symbol, press Up key to switch positive
and negative pressure.
The range of DP low limit is 0-999.999.

After the Flow Coefficient set is completed, press the MENU key to enter the DP scale submenu. Press the right button to move the cursor position, the up and down keys to modify the value. Press the right button to move the cursor to DP unit (Differential pressure unit), and then press Up/Down key to select different units (Pa, KPa and MPa).

Cut-off current:
4.0030 mA

After set the differential pressure range, press the menu button to enter the Cut-off current sub-menu. Press the right button to move the cursor position, the up and down keys to modify the value. Cut-off current is set according to different flowmeters on site. Generally, do not need to set this parameter.).

1.5.2.6 Annubar DP

In input setup, press Up or Down key to select flow signals submenu, press menu key to Flowmeter type Submenu ,and then press Up/Down key to select “Annubar DP”.

- 1.Query and exp.
- 2.Com set
- 3.Input setup
- 4.Output setup

Setup Password
0*****

- 1.Flow signals
- 2.Tempe.signals
- 3.Press.signals

Medium select:
Saturated stm. T

Flowmeter type:
Annubar DP

There are nine parameters in Annubar DP: Signal type, Pipe diameter, Drag coefficient, Expansibility, Flow coefficient, DP unit, DP low scale, DP high scale and Cut-off current.

After the flowmeter type is set, press the MENU key to switch to the signal type submenu. There are two signal types: 4-20mA No sqrt, 4-20mA sqrt. In this manual, it only introduces 4-20mA No sqrt, the others refer to 4-20mA No sqrt. Press Up key to select different signal types.

Sign type:
4-20mA no sqrt

After set Signal type, press menu key to Pipe Diameter Submenu, press Right key to shift cursor on Cursor position, and then press Up/Down key to change this value.

Pipe diameter:
0000.0000 mm

After set Pipe Diameter, press menu key to Drag Coefficient Submenu, press Right key to shift cursor on Cursor position, and then press Up/Down key to change this value.

Drag coe.:
0000.0000 mm

After set Drag Coefficient, press menu key to Expansibility Submenu
press Right key to shift cursor on Cursor position, and then press Up/Down
key to change this value.

Expansibility:
0.00000

After set Expansibility, press menu key to Flow coe. Submenu,
press Right key to shift cursor on Cursor position, and then press Up/Down
key to change this value.

Flow coe.:
0000.0000

DP scale:
Lower: +0000.000
Upper: +0000.000
Unit: kPa

Note: When shifting the cursor on the +/-
symbol, press Up key to switch positive
and negative pressure.
The range of DP low limit is 0-999.999.

After the Flow Coefficient set is completed, press the MENU key to enter the DP scale submenu. Press the right button to move the cursor position, the up and down keys to modify the value. Press the right button to move the cursor to DP unit (Differential pressure unit), and then press Up/Down key to select different units (Pa, KPa and MPa).

Cut-off current:
4.0030 mA

After set the differential pressure range, press the menu button to enter the Cut-off current sub-menu. Press the right button to move the cursor position, the up and down keys to modify the value. Cut-off current is set according to different flowmeters on site. Generally, do not need to set this parameter.).

1.5.2.7 Elbow DP

In input setup, press Up or Down key to select flow signals submenu, press menu key to Flowmeter type Submenu ,and then press Up/Down key to select “Elbow DP”.

- 1.Query and exp.
- 2.Com set
- 3.Input setup
- 4.Output setup

Setup Password
0*****

- 1.Flow signals
- 2.Tempe.signals
- 3.Press.signals

Medium select:
Saturated stm. T

Flowmeter type:
Elbow DP

There are nine parameters in Elbow DP: Signal type, Pipe diameter, Bend radius, Expansibility, Flow coefficient, DP unit, DP low scale, DP high scale and Cut-off current.

After the flowmeter type is set, press the MENU key to switch to the signal type submenu. There are two signal types: 4-20mA No sqrt, 4-20mA sqrt. In this manual, it only introduces 4-20mA No sqrt, the others refer to 4-20mA No sqrt. Press Up key to select different signal types.

Sign type:
4-20mA no sqrt

After set Signal type, press menu key to Pipe Diameter Submenu, press Right key to shift cursor on Cursor position, and then press Up/Down key to change this value.

Pipe diameter:
0000.0000 mm

After set Pipe Diameter, press menu key to Bend Radius Submenu, press Right key to shift cursor on Cursor position, and then press Up/Down key to change this value.

Bend radius:
000.00000

After set Bend Radius, press menu key to Expansibility Submenu
press Right key to shift cursor on Cursor position, and then press Up/Down
key to change this value.

Expansibility:
0.00000

After set Expansibility, press menu key to Flow coe. Submenu,
press Right key to shift cursor on Cursor position, and then press Up/Down
key to change this value.

Flow coe.:
0000.0000

DP scale:
Lower: +0000.000
Upper: +0000.000
Unit: kPa

Note: When shifting the cursor on the +/- symbol, press Up key to switch positive and negative pressure.
The range of DP low limit is 0-999.999.

After the Flow Coefficient set is completed, press the MENU key to enter the DP scale submenu. Press the right button to move the cursor position, the up and down keys to modify the value. Press the right button to move the cursor to DP unit (Differential pressure unit), and then press Up/Down key to select different units (Pa, KPa and MPa).

Cut-off current:
4.0030 mA

After set the differential pressure range, press the menu button to enter the Cut-off current sub-menu. Press the right button to move the cursor position, the up and down keys to modify the value. Cut-off current is set according to different flowmeters on site. Generally, do not need to set this parameter.).

1.5.2.8 Linear current

In input setup, press Up or Down key to select flow signals submenu, press menu key to Flowmeter type Submenu ,and then press Up/Down key to select “Linear current”.

- 1.Query and exp.
- 2.Com set
- 3.Input setup
- 4.Output setup

Setup Password
0*****

- 1.Flow signals
- 2.Tempe.signals
- 3.Press.signals

Medium select:
Saturated stm. T

Flowmeter type:
Linear current

After the flowmeter type is set, Press the menu button to enter the current and the corresponding range set.

Linear I: Sect 0
I: 00.0000 mA
Flow:00000000.000
Flow unit: m3/h

Linear current:

Set the segment current and the corresponding range, can be set in segments, section number is 0-9.

I: Segment current value, input range 00.0000-99.9999.

Flow: The flow value corresponding to different current segments. Input range 0000000.000-9999999.999. Press the right button to set the cursor position, up and down keys to change the value. Set the unit according to the display unit

1.5.2.9 Damping and log interval

After set all the flow signals, press the MENU button to enter the Damping Time and Log interval Time sets submenu.

Damping: 00 sec
Log interval:
00:00:05

Press Right key to shift cursor, and press Up/Down key to change time value, damping time range is 0-30s.

Log record preservation interval, Hours / minutes / seconds. set parameters press Right key to shift cursor, and then press Up/Down key to set the values.

1.5.2.10 Low Flow Cutoff

After set the damping time, press the MENU key to enter the lower flow cut-off submenu.

Low flow cutoff:
00003.0000 m ³ /h

Press the right button to move the cursor, press the up / down button to change the flow cut-off value, the set range is 0-99999.999, the unit is the same as the display unit. Low Flow Cutoff is set according to different flowmeters on site. Generally, do not need to set this parameter.

1.5.2.11 Flow factor

After set the Low Flow Cutoff, press the MENU key to enter the Flow factor submenu.

Press the right button to move the cursor, press the up / down button to change the flow cut-off value,

Flow factor:
0001.0000

1.5.2.12 Temperature signals

This submenu affects the performance and accuracy of instrument, please be careful when operating. Set the flow signal parameters, temperature parameters, pressure parameters. In main menu, press Up or Down key to select temperature signals submenu, and then press ENTER key to enter. In input setup, press Up or Down key to select Temperature signals submenu, then press the menu button to enter.

1.Query and exp.
2.Com set
3.Input setup
4.Output setup

Setup Password

0*****

1.Flow signals
2.Tempe.signals
3.Press.signals

T sensor:
PT100
Constant:
+0180.00 °C

T sensor:
4-20mA
Constant:
+0180.00 °C

There are five temperature sensor types: Pt100, Pt1000,4-20mA, 0-10mA, setup (set temperature).

When the T sensor is selected 4-2mA or 0-10mA signal, it needs to corresponding temperature range.

Press the menu key to enter the upper and lower temperature limit sets, set parameters press Right key to shift cursor, and then press Up/Down key to set the values.

After set the temperature sensor and range, press the MENU key to enter the temperature zero set, set parameters press Right key to shift cursor, and then press Up/Down key to set the values.

After set the zero temperature, press the MENU key to enter the upper and lower temperature limit set submenu, If the temperature is out of the range, it will set temperature to compensate.


T scale:
4mA:+0000.00 °C
20mA:+0000.00°C

T zero:
+00.000 °C

T Upper/lower:
Lower:-0050.00°C
Upper:+0050.00°C

1.5.2.13 Pressure signals

This submenu affects the performance and accuracy of instrument, please be careful when operating. Set the flow signal parameters, temperature parameters, pressure parameters. In main menu, press Up or Down key to select pressure signals submenu, and then press menu key to enter. In input setup, press Up or Down key to select Pressure signals submenu, then press the menu button to enter.



There are four pressure sensor types: 4-20mA GP (4-20mA gauge pressure), 4-20mA AP (4-20mA absolute pressure), Setup GP (set gauge pressure) and Setup AP (set absolute pressure). Press the menu key to enter the upper and lower temperature limit sets, set parameters press Right key to shift cursor, and then press Up/Down key to set the values.

After set the temperature sensor and range, press the MENU key to enter the pressure zero and Atmospheric pressure set, set parameters press Right key to shift cursor, and then press Up/Down key to set the values.

After set the pressure zero, press the MENU key to enter the upper and lower pressure limit set submenu, If the pressure is out of the range, it will use set pressure to compensate.

P scale(kPa):
4mA: +00000.000
20mA: +01600.000

P zero:
+0000.000 kPa
Atmospheric P:
101.325 kPa

P Upper/lower (kPa)
Lower: +00000.00
Upper: +02000.00

1.6 Output setup

In the main menu, press the up or down arrow key to select the output set menu, then press the MENU key to enter.

In the "Output sets" submenu, there are current output, frequency output, alarm output. Press Up or Down to select Set Output Type and press the Menu key to enter the submenu.

- 1.Query and exp.
- 2.Com set
- 3.Input setup
- 4.Output setup

- 1.Current output
- 2.Freque. output
- 3.Alarm output1
- 4. Alarm output2

1.6.1 Current output

In the output setup menu, press the up and down keys to move the cursor to the current output, then press the menu key to enter the current output channel sets.

- 1.Current output
- 2.Freque. output
- 3.Alarm output1
- 4. Alarm output2

Current output:
Mode: 4-20mA
Var.: Flow rate

Current output variable
1. Flow rate
2. Temperature
3. Gauge pressure (MPa)
4. DP (differential pressure, kPa)
5. Density (Kg/m3)
6. Thermal enthalpy (KJ/kg)
7. Power (MJ/h)

Current scale:
4mA: +00000.00
20mA: +01600.00
m3/h

Note: When shifting the cursor on the +/- symbol, press Up key to switch positive and negative value.

After entering the current output menu, right-click to move the cursor to the output variable type. There are 7 output variables: Flow rate, Temperature, Gauge pressure, DP, Differential pressure, KPa, Thermal enthalpy KJ / kg), Power (MJ / h), press the up key to switch the output variable type. Then press the MENU button to enter the variable output range upper and lower limits, set parameters press Right key to shift cursor, and then press Up/Down key to set the values.

1.6.2 Frequency output

In the output setup menu, press the up and down keys to move the cursor to the frequency output, then press the menu key to enter the frequency output channel sets.

- 1.Current output
- 2.Freque. output
- 3.Alarm output1
- 4. Alarm output2

Freq. output:
Scaled freq.

1.6.2.1 Scaled Frequency

In the output sets menu, enter the frequency output menu, the up keys to move the frequency output type to Scaled Frequency, then press the MENU button to enter the frequency range corresponding to the output range set.set parameters press Right key to shift cursor, and then press Up/Down key to set the values.

Frequency: Frequency upper and lower limits, range: 0000-5000Hz

flow: flow rate,range: 0-999999.99. Unit with the display unit

1.6.2.2 Equivalent

In the output sets menu, enter the frequency output menu, the up keys to move the Frequency output type to Equivalent, then press the MENU button to enter the frequency range corresponding to the output range set. Set parameters press Right key to shift cursor, and then press Up/Down key to set the values. Output flow total, when the equivalent coefficient is set to 1m3, the meter every 1m3 flow total, then the instrument output a pulse. range: 0-999.9999.

Freq. output:
Scaled freq.

Frequen. output:
Freq:0000-5000
Flow:0-000000.00
m3/h

Freq. output:
Equivalent

Equivalent coe.:
001.0000 m3

1.6.3 alarm output

In the output setup menu, press the up and down keys to move the cursor to the alarm output, then press the menu key to enter the alarm output, channel sets. (Noted: Normally the alarm channel defaults to only one channel)

- 1.Current output
- 2.Freque. output
- 3.Alarm output1
- 4. Alarm output2

Alarm1: Flow LRV
Value: m3/h
+00000000.000
Hyst:000.200

Alarm 1 variable type
1. Flow URV (Flow rate upper scale)
2. Flow LRV (Flow rate lower scale)
3. T URV (Temperature upper scale)
4. T LRV (Temperature lower scale)
5. P URV (Pressure upper scale)
6. P LRV (Pressure lower scale)

1.6.3.1 alarm1 output

In the output setup menu, press the up and down keys to move the cursor to the alarm1 output, then press the menu key to enter the alarm output, channel set. There are 6 alarm variables: Flow rate upper scale, Flow rate lower scale, Temperature upper scale, Temperature lower scale, Pressure upper scale, Pressure lower scale. After set the alarm variables, set the alarm value and hysteresis value. set parameters press Right key to shift cursor, and then press Up/Down key to set the values.

1.6.3.2 alarm2 output (Optional)

In the output setup menu, press the up and down keys to move the cursor to the alarm2 output, then press the menu key to enter the alarm output, channel set. There are 6 alarm variables: Flow rate upper scale, Flow rate lower scale, Temperature upper scale, Temperature lower scale, Pressure upper scale, Pressure lower scale. After set the alarm variables, set the alarm value and hysteresis value. set parameters press Right key to shift cursor, and then press Up/Down key to set the values.

Alarm: Quantity
Value: m³
00000001.000

1.7 Total reset

In the main menu, press the up or down arrow key to select the Total reset menu, then press the MENU key to enter.

2.Com set	Reset passwd:	Total reset:
3.Input setup	0*****	00000000.000 m3
4.Output setup		
5.Total reset		

1.7.1 Total reset

Enter the password to enter the total clear menu, by modifying the value of zero and modify the cumulative flow.

set parameters press Right key to shift cursor, and then press Up/Down key to set the values.

1.7.2 Log reset

Log reset: No

After the accumulated flow rate clear set is completed, press the MENU key to enter the log record clear.

When clearing the log, press the up key to change "ON" to "yes", then press the MENU key, the log record will be cleared completely, and the meter will save the log record again.

1.8 Calibration

This submenu is used to calibrate the internal analog signal, and it affects the accuracy of instrument. If there are no resistance box, standard current source, multimeter and other calibration equipment's, please do not use this submenu!

In main menu, press Up or Down key to select Calibrate submenu, and then press MENU key to enter.

3.Input setup
4.Output setup
5.Total reset
6.Calibration

Calib passwd:
0*****

1.I output cali.
2.I input calib.
3.Temper. calib.

Note: The Total reset submenu has password protection. When inputting password, press Left key to shift the cursor, and press Up or Down key to increase or decrease the number. The default password is 000000, users can modify the password according to 1.10 Password.

1.8.1 Current output calibrate

In calibrate submenu, press Up or Down key to select Current Output, and then press MENU key to enter.

When calibrating, it needs multimeter to measuring the output current, and then input this current value into "mea.I".

1.I output cali.
2.I input calib.
3.Temper. calib.

I output:
Mea.I:03.9810mA
Out. I:04.0000mA

I output:
Mea.I:20.0330mA
Out. I:20.0000mA

I output:
Mea.I:20.0330mA
Out. I:20.0000mA
Successful!

The meter adopts two-point calibration. When calibrating, the meter prompts 4mA, then the output current is about 4mA. Input the value of the multimeter into the meter, then press the MENU key to enter the next point. At this moment, it indicates 20mA, then the output current is about 20mA. Multimeter to detect the value entered into the meter, and then press the menu button, the meter prompts to modify successfully. And then return to calibrate submenu. set parameters press Right key to shift cursor, and then press Up/Down key to set the values.

1.8.2 Current input calibrate

In calibrate submenu, press Up or Down key to select Current Input, and then press MENU key to enter. When calibrating, it needs standard current source to input current to instrument according to “Input” prompt. For example, of calibrating Flow Current, select Flow Current, and press MENU key to calibrate. Input 4mA for zero-scale, the instrument will display a measuring value mea. I approximating 4mA, and then press MENU key to enter full-scale. Input 20mA for full-scale, the instrument will display a mea. I approximating 20mA, and then press MENU key to finish calibration. After calibration, the instrument will display “Successful”, and then return to calibrate submenu.

1.I output cali. 2.I input calib. 3.Temper. calib.	1.Flow current 2.Temp. current 3.Pres. current	I input: Std. I:04.0000mA Mea.I:03.9790mA	I input: Std. I:20.0000mA Mea.I:20.0100mA	I input: Std. I:20.0000mA Mea.I:20.0100mA Successful!
--	--	---	---	--

The calibration method of temperature and pressure is the same as that of Flow current.

1.8.3 Temperature Input

In calibrate submenu, press Up or Down key to select Temperature, and then press MENU key to enter.

When calibrating, it needs standard resistance box to input resistance to instrument according to R value.

1.I output cali. 2.I input calib. 3.Temper. calib.	Calib. Temp.: L Std. v: +0000.0 °C Mea.v:+0000.0 °C	Calib. Temp.: H Std. v: +0000.0 °C Mea.v:+0001.2 °C	Calib. Temp.: H Std. v: +0400.0 °C Mea.v:+0397.3 °C	Calib. Temp.: H Std. v: +0400.0 °C Mea.v:+0397.3 °C
--	--	--	--	--

After calibration, the instrument will display “Successful”, and then return to calibrate submenu. set parameters press Right key to shift cursor, and then press Up/Down key to set the values.

1.9 Display unit

In the main menu, press the up or down arrow key to select the output set menu, then press the MENU key to enter.

In the "Display unit" submenu, there are display unit and display param. Press Up or Down to select Set Output Type and press the Menu key to enter the submenu.

- 4. Output setup
- 5. Total reset
- 6. Calibration
- 7. Display unit

- 1. Display unit
- 2. Display Parma

In calibrate submenu, press Up or Down key to select Display unit, and then press MENU key to enter.

Set parameters Press the right button to move the cursor, and then press the up button to switch units.

- 1. Display unit
- 2. Display Parma

Flow unit: m³/h
Total unit: m³
Temp unit: °C
Press unit: kPa

Display Unit
Flow: Nm ³ /h, Nl/h, Nl/m, t/h, kg/h, m ³ /h, l/h and l/m
Pressure: MPa and KPa
Temperature: °C and °F

In calibrate submenu, press Up or Down key to select Display Parma, and then press MENU key to enter.

- 1. Displav unit
- 2. Display Parma

- 1. Tem. /Pr.
- 2. Current
- 3. Date/Time
- 4. Total
- 5. Diff.p
- 6. Density

Displav mode:
1sec loop

Decimal: 3

Press Right key to select display mode, and press MENU key to enter. Press Right key to shift cursor on display options, and press Down key to switch the options displaying or not (✓ means options displaying, else no displaying). After set, press MENU key to return display submenu. After set the display mode, press the MENU key to enter the cycle display interval and flowmeter display decimal point. Interval time range 1-9sec, decimal point range 0-3. set parameters press Right key to shift cursor, and then press Up/Down key to set the values.

1.10 Password

In the main menu, press the up or down arrow key to select the Password menu, then press the MENU key to enter.

5.Total reset
6.Calibration
7.Display unit
8.Password

1.Input Ch. pwd
2.Para. rst pwd
3.Cali. Ch. pwd

1.Input ch. pwd
Old pwd: 0*****
New pwd: *****

1.Input ch. pwd
Old pwd: *****
New pwd: *****1
Successful!

Press Right key to shift cursor on Input channel, press MENU key to enter setup password menu, input old and new passwords, and then press MENU key, it will display “Successful!”. set parameters press Right key to shift cursor, and then press Up/Down key to set the values.

The setup method of calibrate and total reset password is the same as that of Input channel password.

1.11 Date and time

In the main menu, press the up or down arrow key to select the Date and time menu, then press the MENU key to enter. set parameters press Right key to shift cursor, and then press Up/Down key to set the values.

6.Calibration
7.Display unit
8.Password
9.Date and time

Setup clock:
2018-01-25
10:57:21

1.12 Self-test

In the main menu, press the up or down arrow key to select the Self-test menu, then press the MENU key to enter. This submenu to check the details of running status, √ is ok, and × means this option is abnormal.


After self-test, the display will turn to main menu.

7.Display unit
8.Password
9.Date and time
10.Self-test

Self-test
Clock √ Memory √
Power √ AD con √
Param √ Amplif √

Part 2 Wirings

2.1 Wiring Terminals



2.2 Terminals Definition

No.	Definition	N	Definition
1	Current output +	14	Public GND
2	Current output -	15	Pulse output +
3	RS-485 (A)	16	Pulse output -
4	RS-485 (B)	17	Alarm 1 normally-closed
5	Power supply +24V	18	Alarm 1 normally-open
6	Power supply GND	19	Alarm 1 common
7	AC80-220V N	20	Alarm 2 normally-open
8	AC80-220V L	21	Alarm 2 common
9	Pt100, A	22	24V (+) output
10	Pt100, B	23	GND
11	Pt100, B	24	Pressure current input
12	Temperature current input	25	Flow current input
13	24V (+) output	26	Flow pulse input